

TDS – STONE BUILT 2K Low VOC Primer, Grey

Components-

- 2K LOW VOC Primer Grey • ABX-120302
- ABX-130300 2K Hardener •

Mixing Ratio (4:1)

Mix four parts Primer with one part Hardener. •

Pot Life

• 1 Hour.

Application

- Apply two (2) to three (3) medium – wet to wet coats. Allow each coat to flash between coats.
- 50% Overlap. •

Flash / Dry Times

Air Dry @ 70°F (21°C)

- Flash 5 – 10 minutes • To Sand 1 hour •
 - 1 hour
- To Topcoat

Force Drying @ 145°F (60°C)

 Bake Time 20 minutes Deliver/Polishing/Recoating After cool down •

Spray Gun Set Up	
 HVLP/LVLP - Fluid Tip Size 	1.4 mm - 1.8 mm
Air Pressure	HVLP Inlet (30 psi) / Gravity Feed (30 – 40 psi)

Personal Protection

- For use by trained professionals only.
- Read label, directions, and MDDS before use.
- Use appropriate Personal Protective Equipment while mixing and spraying.